

MRL10 Mini Rock Lights




10 Watt, Submersible

Mini Rock Lights

Instructions for Operation • Safety • Warranty

Thank you for purchasing the EasyPro submersible mini rock light. With this pond light you can make your fountain glow, illuminate your pond from within, highlight your waterfall and extend the enjoyment of your water feature in the evening hours. Replacement bulbs are available.



Safety and Electrical Connections:

1. Always disconnect the electricity supply before handling, maintaining, repairing or installing any pond equipment.
2. Light(s) must be attached to a 12 volt UL listed transformer.
3. Never hook the light up directly to a 110 volt or higher outlet.
4. Connect the 12 volt transformer to a 110 volt receptacle that is protected by a Ground Fault Circuit Interrupter (GFCI).
5. Do not use this product in bathrooms or swimming pools.
6. All electrical work must be performed by a qualified technician. Always follow the National Electrical Code (NEC) or the Canadian Electrical Code as well as all local, state and provincial codes. Code questions should be directed to your local electrical inspector. Failure to follow electrical codes and OSHA safety standards may result in personal injury or equipment damage. Failure to follow manufacturer's installation instructions may result in electrical shock, fire hazard, personal injury or death, damaged equipment, provide unsatisfactory performance and may void manufacturer's warranty.



Installation

1. Before installing the product make sure to check in the box for damaged or missing parts. Contact EasyPro if pieces are missing or damaged.
2. Be sure the power is disconnected before installing the lights.
3. Place the light in the desired location of your water feature.
4. The submersible lights must be covered with water at all times. Do not allow the water level to drop below the lights, as this will cause the lenses to crack and the bulbs to burn up due to excess heat.
5. Run the cable back to the transformer.
6. When installing the light cable, run the wire back to the transformer, remove the protective cap off of one of the terminals on the transformer. Insert the two prong plug into the terminal and screw down the nut to make a weather tight seal.
7. Install transformer on a timer and enjoy.
8. Recommended 12 volt transformer for use with multiple lights is the MT60/60 watt.



Service and Maintenance of Submersible Lights

1. **Disconnect the transformer from the power supply before service.**
2. All parts of the lighting system should be checked on a regular basis to make sure the system is functioning properly.
3. To replace a bulb, bring the light to the surface.
4. Push in on the black cord and remove the light from the rock.
5. Unscrew the black plastic cover and remove. Remove the glass lens. Be sure not to loose the o-ring under the lens. Pull out on the light bulb and remove it from the ceramic base.
6. When installing the new light, **do not touch the lens with your fingers.** Push the new bulb into the ceramic socket by grasping the socket and pushing the two prongs into socket.
7. Insert the ceramic socket and the new bulb back into the light housing.
8. Install the clear lens and screw the black plastic cover back on, **do not overtighten.**
9. Push the light back into the rock shell.
10. If installing the colored lens, remove from the package and remove the desired lens. Remove the cover and the clear glass lens, replace with the colored lens. Install black cover and put back into the water.

Replacement Parts for Mini Rock Lights - MRL10

60 watt transformer	MT60
10 watt bulb.....	MRLB
Clear lens.....	MRL10L
Colored lens set	MRLC
3 pack with transformer	MRK3
15' extension cord.....	LEDEX

Warranty:

This product is warranted against any mechanical or material defects for a period of three years from the date of purchase (bulbs are a wear item and are not covered by warranty). Warranty only covers properly installed and maintained units.

The warranty does not cover normal wear and tear, nor any deterioration suffered through overloading, improper use, negligence or accident. Similarly, any modification made by the purchaser to the product will cause the warranty to be null and void.

All returned items will be inspected to determine cause of failure before warranty is approved.

Warranty does not cover any cost associated with the installation or removal of the product subject to warranty claim.

An RA number must be obtained by calling EasyPro Pond Products at 800-448-3873. It is your responsibility to pay the return shipping charges. Be sure to include the RA number, original receipt (in the form of an invoice or sales receipt), name, return address and phone number inside of the package. No warranty claims will be honored without the original receipt.

Ensure the product is properly packaged and insured for the replacement value. Damage due to improper packaging is the responsibility of the sender.

The manufacturer or supplier shall not be held liable for any damages caused by defective components or materials of this product; or for loss incurred because of the interruption of service; or any consequential/incidental damages and expenses arising from the production, sale, use or misuse of this product.

The manufacturer or supplier shall not be held liable for any loss of fish, plants or any other livestock as a result of any failure or defect of this product.

